

AUTRONICA TRAINING

2027 Course Catalog

Confidence through Competence

How to use this catalog

1. Find your course in the overview. Its name links to the full course description.
2. Click See dates to jump to its schedule, then pick a date, focus area, and language.
3. Click Buy to purchase your place in the Autronica training shop. (Please note: your company must be a registered user in the AutroShop. For questions, please contact shop.autronica@autronicagroup.com.

Please note:

- Before you purchase a training, please note our Training Participation Policy – Autronica
- When interested in purchasing a recertification, please review our Autronica Academy Recertification Policy - Autronica

Catalog at a glance

Course	Format	Duration	
AutroSafe 4			
AutroSafe 4 Certification (Land, Maritime)	Classroom, Trondheim	3 days (Land); 2 days (Maritime)	**See dates**
AutroSafe 4 Certification (Energy)	Classroom, Stavanger	3 days	**See dates**
AutroSafe 4 Operator/Maintenance	E-learning	Self-paced	**Buy**
AutroSafe 4 Installer	E-learning	Self-paced	**Buy**
AutroPrime			
AutroPrime Certification	Live online (Zoom)	2 days	**See dates**
AutroMaster V			
AutroMaster V Certification	Classroom, Trondheim	1 day	**See dates**
AutroMaster 4			
AutroMaster 4 Operator/Maintenance	E-learning	Self-paced	**Buy**
Recertifications			
AutroSafe 4 Re-Certification	E-learning	Self-paced	**Buy**
AutroPrime Re-Certification	E-learning	Self-paced	**Buy**
AutroMaster V Re-Certification	E-learning	Self-paced	**Buy**



AutroSafe 4

AutroSafe 4 Certification

The AutroSafe 4 Certification happens in two stages: a digital certification preparation course, followed by the in-person certification course in Stavanger; LAND and MARITIME sessions run in Trondheim; ENERGY (POG/E) sessions run in Stavanger, in English. Course descriptions: Land and Maritime · Energy.

Dates	Focus	Language	Location	Course ID	Shop
11–13 Jan	Land	Norwegian	Trondheim	116-AS4-Cert-L-11Jan	Buy
18–20 Jan	Energy	English	Stavanger	116-AS4-Cert-E-18Jan	Buy
19–20 Jan	Maritime	English	Trondheim	116-AS4-Cert-M-19Jan	Buy
15–17 Feb	Land	English	Trondheim	116-AS4-Cert-LGL-15F	Buy
8–10 Mar	Land	Norwegian	Trondheim	116-AS4-Cert-L-8Mar	Buy
15–17 Mar	Land	English	Trondheim	116-AS4-Cert-LGL-15M	Buy
12–14 Apr	Energy	English	Stavanger	116-AS4-Cert-E-12Apr	Buy
10–12 May	Land	Norwegian	Trondheim	116-AS4-Cert-L-10May	Buy
19–20 May	Maritime	English	Trondheim	116-AS4-Cert-M-19May	Buy
9–11 Aug	Energy	English	Stavanger	116-AS4-Cert-E-9Aug	Buy
13–15 Sep	Land	Norwegian	Trondheim	116-AS4-Cert-L-13Sept	Buy
13–15 Sep	Energy	English	Stavanger	116-AS4-Cert-E-13Sept	Buy
16–17 Sep	Maritime	English	Trondheim	116-AS4-Cert-M-16Sept	Buy
27–29 Sep	Land	English	Trondheim	116-AS4-Cert-LGL-27S	Buy
27–29 Sep	Energy	English	Stavanger	116-AS4-Cert-E-27Sept	Buy
18–20 Oct	Land	Norwegian	Trondheim	116-AS4-Cert-L-18Oct	Buy
25–27 Oct	Land	English	Trondheim	116-AS4-Cert-LGL-25O	Buy
25–27 Oct	Energy	English	Stavanger	116-AS4-Cert-E-25Oct	Buy
28–29 Oct	Maritime	English	Trondheim	116-AS4-Cert-M-28Oct	Buy
15–17 Nov	Energy	English	Stavanger	116-AS4-Cert-E-15Nov	Buy
6–8 Dec	Land	Norwegian	Trondheim	116-AS4-Cert-L-6Dec	Buy
9–10 Dec	Maritime	English	Trondheim	116-AS4-Cert-M-9Dec	Buy

AutroSafe 4 e-learning

Self-paced courses, available year-round.

Course	Language	Course ID	Shop
AutroSafe 4 Operator/Maintenance	English	116-AS4-OPM-D	Buy
AutroSafe 4 Installer	English	116-AS4-IN-D	Buy



AutroPrime

AutroPrime Certification

This course is conducted as a online sessions on Zoom. The Zoom registration link will be sent separately by email. Each participant joins on their own computer. LAND sessions alternate between Norwegian and English; MARITIME sessions are in English. Read the full course description.

Dates	Focus	Language	Location	Course ID	Shop
25–26 Jan	Land	Norwegian	Zoom	116-AP-Cert-L-25Jan	Buy
27–28 Jan	Maritime	English	Zoom	116-AP-Cert-M-27Jan	Buy
22–23 Feb	Land	Norwegian	Zoom	116-AP-Cert-L-22Feb	Buy
24–25 Feb	Land	English	Zoom	116-AP-Cert-L-24Feb	Buy
19–20 Apr	Land	Norwegian	Zoom	116-AP-Cert-L-19Apr	Buy
21–22 Apr	Land	English	Zoom	116-AP-Cert-L-21Apr	Buy
24–25 May	Maritime	English	Zoom	116-AP-Cert-M-24May	Buy
14–15 Jun	Land	Norwegian	Zoom	116-AP-Cert-L-14Jun	Buy
16–17 Jun	Land	English	Zoom	116-AP-Cert-L-16Jun	Buy
23–24 Aug	Land	Norwegian	Zoom	116-AP-Cert-L-23Aug	Buy
25–26 Aug	Land	English	Zoom	116-AP-Cert-L-25Aug	Buy
12–13 Oct	Land	Norwegian	Zoom	116-AP-Cert-L-12Oct	Buy
14–15 Oct	Maritime	English	Zoom	116-AP-Cert-M-14Oct	Buy
22–23 Nov	Land	Norwegian	Zoom	116-AP-Cert-L-22Nov	Buy
24–25 Nov	Land	English	Zoom	116-AP-Cert-L-24Nov	Buy
29–30 Nov	Maritime	English	Zoom	116-AP-Cert-M-29Nov	Buy



AutroMaster V

AutroMaster V Certification

One-day classroom sessions in Trondheim, in English. Read the full course description.

Date	Language	Location	Course ID	Shop
5 Mar	English	Trondheim	116-AMV-Cert-5Mar	Buy
6 Aug	English	Trondheim	116-AMV-Cert-6Aug	Buy

AutroMaster 4

AutroMaster 4 Operator/Maintenance

Self-paced e-learning, available year-round.

Course	Language	Course ID	Shop
AutroMaster 4 Operator/Maintenance	English	116-AM4-OPM-ENG	Buy

Recertifications

Self-paced e-learning, available year-round. Re-Certification courses keep an existing certification valid. Please review our Autronica Academy Recertification Policy - Autronica BEFORE purchasing a recertification.

Course	Language	Course ID	Shop
AutroSafe 4 Re-Certification	English	116-AS4-R-ENG	Buy
AutroSafe 4 Re-Certification	Norwegian	116-AS4-R-NO	Buy
AutroPrime Re-Certification	English	116-AP-R-ENG	Buy
AutroPrime Re-Certification	Norwegian	116-AP-R-NO	Buy
AutroMaster V Re-Certification	English	116-AMV-R-ENG	Buy